

RANTASAUNA / TUB, INSTRUCTIONS

Please read these instructions carefully before using the tub at the beach sauna. If the tub or stove is damaged due to improper use, the renter is responsible for damages. Remember that the use of removable tubs at the beach sauna is prohibited under penalty of fine in order not to damage the courtyard.

The most important instructions

1. Never light the stove if the heating pipes are not completely covered by water!
2. Make sure that the water level does not drop below the level of heating pipes even when many people leave the bathing tub at the same time.
3. Drain warm water from the bathing tub as soon as you stop using the tub! If you let the water cool down first, it may freeze in the water drain.
4. When emptying the tub, open the red handle at the bottom edge of the stove in addition to the drain plug. Finally, use the water broom to scrape the rest of the water from the base of the tub into the drain. Make sure that there is no water left anywhere when you have finished using the tub!
5. Do not walk on the cover even when it is on the ground.

Instructions - before use:

1. Open the locks of the tub cover and lift the cover aside with your friend. The cover is heavy and you need 2-3 people to safely remove it.
2. Close the valve on the bottom of the stove and the plug on the base of the tub.
3. Connect the hose to the water supply under the terrace roof. Place the hose in the tub and open the water supply.
4. Fill the tub full of water. Water is already adequately warm, so you do not have to hurry to light the stove. It takes approximately one and a half hours to fill the tub.
5. When the tub is full, i.e. when the water level is at least entirely above the heating pipes, you may open the lock of the stove, empty the ashes into the white ash bucket and light the stove.
6. Maintain a small fire in the stove, which keeps the water warm.

Instructions - after use:

1. After you stop using the tub, open the drain plug immediately, as well as the faucet on the bottom edge of the stove (see the picture below) and leave them open. When you drain warm water, the water drain does not freeze even in the winter. It takes approximately an hour to empty the tub.
2. When the tub is empty, rinse it with a hose and brush the surfaces lightly. Use the water broom to drain the rest of the water into the outlet.
3. Return the hose and cleaning equipment to their place below the spiral staircase.
4. Lift the cover in place (2-3 people) and make sure that red arrows on the cover and the tub are in the same position.
5. Lock the stove (one lock) and the cover (one lock). Cleaning equipment and the hose are placed under the spiral staircase inside the beach sauna.

The following items and cleaning supplies can be found inside under the stairs.
(During the summer time the hose might also be outside.)

Checklist:

Item	How many?	Is the condition okay?
Yellow plastic hose (keltainen muoviletku)	1	
Big brush (pitkävartinen harja)	1	
Small brush (pieni harja)	1	
Sweeper (pitkävartinen lasta)	1	
Lock (lukko)	2	



Make sure to open the water jacket tap of the stove after use. The tap is closed in this picture.
The tap opens by moving the red handle laterally towards the tub.